



## APPLICABILITY TABLE

PRODUCT
SE868-V3 EVK



*SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE*

**Notice**

While reasonable efforts have been made to assure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. The information in this document has been carefully checked and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies or omissions. Telit reserves the right to make changes to any products described herein and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Telit does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

It is possible that this publication may contain references to, or information about Telit products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Telit intends to announce such Telit products, programming, or services in your country.

**Copyrights**

This instruction manual and the Telit products described in this instruction manual may be, include or describe copyrighted Telit material, such as computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Telit and its licensors contained herein or in the Telit products described in this instruction manual may not be copied, reproduced, distributed, merged or modified in any manner without the express written permission of Telit. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit, as arises by operation of law in the sale of a product.

**Computer Software Copyrights**

The Telit and 3rd Party supplied Software (SW) products described in this instruction manual may include copyrighted Telit and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and other 3rd Party supplied SW certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Telit or other 3rd Party supplied SW computer programs contained in the Telit products described in this instruction manual may not be copied (reverse engineered) or reproduced in any manner without the express written permission of Telit or the 3rd Party SW supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit or other 3rd Party supplied SW, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.



## Usage and Disclosure Restrictions

### License Agreements

The software described in this document is the property of Telit and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

### Copyrighted Materials

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Telit

### High Risk Materials

Components, units, or third-party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

### Trademarks

TELIT and the Stylized T Logo are registered in Trademark Office. All other product or service names are the property of their respective owners.

### Third Party Rights

The software may include Third Party Right software. In this case you agree to comply with all terms and conditions imposed on you in respect of such separate software. In addition to Third Party Terms, the disclaimer of warranty and limitation of liability provisions in this License shall apply to the Third Party Right software.

TELIT HEREBY DISCLAIMS ANY AND ALL WARRANTIES EXPRESS OR IMPLIED FROM ANY THIRD PARTIES REGARDING ANY SEPARATE FILES, ANY THIRD PARTY MATERIALS INCLUDED IN THE SOFTWARE, ANY THIRD PARTY MATERIALS FROM WHICH THE SOFTWARE IS DERIVED (COLLECTIVELY "OTHER CODE"), AND THE USE OF ANY OR ALL THE OTHER CODE IN CONNECTION WITH THE SOFTWARE, INCLUDING (WITHOUT LIMITATION) ANY WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO THIRD PARTY LICENSORS OF OTHER CODE SHALL HAVE ANY LIABILITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST PROFITS), HOWEVER CAUSED AND WHETHER MADE UNDER CONTRACT, TORT OR OTHER LEGAL THEORY, ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE OTHER CODE OR THE EXERCISE OF ANY RIGHTS GRANTED UNDER EITHER OR BOTH THIS LICENSE AND THE LEGAL TERMS APPLICABLE TO ANY SEPARATE FILES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Copyright © Telit Communications S.p.A. 2015.



## Contents

<b>1. Introduction.....</b>	<b>8</b>
1.1. Scope.....	8
1.2. Contact Information, Support .....	8
1.3. Text Conventions .....	8
1.4. Related Documents.....	9
<b>2. Evaluation Kit Requirements.....</b>	<b>10</b>
<b>3. Evaluation Kit Description .....</b>	<b>11</b>
3.1. Evaluation Kit Contents .....	11
3.2. Evaluation Kit .....	13
3.3. SE868-V3 Module .....	14
3.4. Evaluation Board Picture.....	15
3.5. Evaluation Board Layout .....	17
3.6. Evaluation Board Schematic Diagram.....	19
<b>4. Evaluation Kit Setup.....</b>	<b>20</b>
4.1. Installing the USB Drivers .....	20
4.2. Installing SiRFLive .....	22
<b>5. Running the SE868-V3 Evaluation Board .....</b>	<b>23</b>
<b>6. Using SiRFLive .....</b>	<b>24</b>
6.1. Starting SiRFLive .....	24
6.2. SiRFLive Windows .....	28
6.2.1. Signal View .....	28
6.2.2. Radar View .....	29
6.2.3. Debug View .....	30
6.2.4. Location View .....	31
6.3. Logging Data.....	32
6.4. Receiver Commands.....	34
6.4.1. Reset commands.....	35
6.4.2. Switching Protocols.....	36



- 6.4.3. Setting the Receiver Type..... 37
- 6.4.4. Enabling 5Hz Update ..... 37
- 6.4.5. OSP MID 136 - Mode Control Command ..... 39
- 7. Updating Firmware with SiRFLive..... 40**
  - 7.1. Flashing Requirements ..... 40
  - 7.2. Flashing Instructions ..... 40
- 8. Software Interface ..... 42**
  - 8.1. NMEA Output Messages ..... 42
  - 8.2. NMEA Input Commands ..... 44
  - 8.3. One Socket Protocol (OSP) Output Messages ..... 44
- 9. Document History..... 45**



## Figures

Figure 3-1 SE868-V3 Evaluation Kit Contents .....	11
Figure 3-2 SE868-V3 Evaluation Kit .....	13
Figure 3-3 SE868-V3 Module .....	14
Figure 3-4 SE868-V3 Evaluation Board.....	15
Figure 3-5 SE868-V EVK board with jumpers.....	16
Figure 3-6 SE868-V3 Evaluation Board Layout .....	17
Figure 3-7 SE868-V3 Evaluation Board Schematic Diagram .....	19
Figure 4-1 Hardware Installation .....	20
Figure 4-2 Identify new COM port .....	21
Figure 6-1 Connection settings window .....	24
Figure 6-2 Click Receiver, then Connect on the menu bar.....	25
Figure 6-3 Switch Comm Settings window.....	25
Figure 6-4 The OSP protocol window .....	26
Figure 6-5 Features, Power Mode window .....	26
Figure 6-6 Full Power Mode window.....	27
Figure 6-7 Verify NMEA window.....	27
Figure 6-8 Satellite signal levels .....	28
Figure 6-9 Satellites by azimuth and elevation .....	29
Figure 6-10 Receiver Messages (OSP ) .....	30
Figure 6-11 Details of the position fix.....	31
Figure 6-12 Log File command.....	32
Figure 6-13 Enter the filename to specify the log file .....	33
Figure 6-14 Receiver commands .....	34
Figure 6-15 Reset Window.....	35
Figure 6-16 Switching to OSP protocol with its default 115200 baud rate .....	36
Figure 6-17 Click Receiver, Receiver Family, then the desired family .....	37
Figure 6-18 Enable 5Hz Nav command.....	38
Figure 7-1 Firmware file selection.....	40
Figure 7-2 Select Firmware file .....	41
Figure 7-3 Successful firmware installation.....	41

## Tables

Table 3-1 SE868-V3 Evaluation Kit Contents .....	12
Table 3-2 SE868-V3 Evaluation Board Components.....	18
Table 6-1 MID 136 - Mode Control command .....	39
Table 8-1 Default NMEA Output Messages .....	42
Table 8-2 Available Messages .....	43
Table 8-3 NMEA Talker IDs .....	43





## 1.4. Related Documents

- SE868-V3 Product User Guide





### 3. Evaluation Kit Description

#### 3.1. Evaluation Kit Contents



Note: The antenna is not visible (under the ground plane)

**Figure 3-1 SE868-V3 Evaluation Kit Contents**



<b>Evaluation Kit Contents</b>
Plastic case
USB cable
Multi-constellation antenna
Ground Plane
USB drive with software and documentation
Evaluation Kit

**Table 3-1 SE868-V3 Evaluation Kit Contents**



### 3.2. Evaluation Kit



Figure 3-2 SE868-V3 Evaluation Kit



### 3.3. SE868-V3 Module



Figure 3-3 SE868-V3 Module



### 3.4. Evaluation Board Picture




Figure 3-4 SE868-V3 Evaluation Board





Figure 3-5 SE868-V EVK board with jumpers



### 3.5. Evaluation Board Layout




Figure 3-6 SE868-V3 Evaluation Board Layout



ID	Description
DL100	LED – System On
DL102	LED – 1 PPS
DL101	LED – Tx Data
SW100	On-Off Switch (1.8V to module On-Off pin)
PL101	USB connector – Power, Ground, Tx, and Rx
S0101	SMA connector – 1PPS output
S0100	SMA connector – RF input
PL100	Tx output
PL102	Module power (current measurement)
PL104	Rx input
PL105	Boot pin to 1.8 V
PL106	1PPS output and ground
PL108	1.8 V regulator enable
PL109	3.3 V regulator enable
PL110	1.8 V module regulator enable
PL111	Active antenna on (remove for passive antenna)
PL112	GPIO 6 to 1.8 V
PL115	GPIO7 to ground



**Table 3-2 SE868-V3 Evaluation Board Components**





## 4. Evaluation Kit Setup

### 4.1. Installing the USB Drivers

Before connecting the SE868-V3 Evaluation Kit, install the necessary USB drivers.

- Double-click the USB driver executable CDM v2.12.00 WHQL Certified.exe, and follow the directions to install the USB drivers.



**Figure 4-1 Hardware Installation**

- Click “Continue Anyway” to install the USB COM port driver
- When the EVK board is connected to a personal computer USB port, the driver will create a COM port.
- Use the Windows “Device Manager” to check the identification of the new COM port. This port identification is necessary for EVK tools to connect to the evaluation kit.





**Figure 4-2 Identify new COM port**

- In this example, the COM port is assigned as COM5



## 4.2. Installing SiRFLive

Minimum PC requirements:

- Pentium CPU 2 GHz
- 1 GB of RAM
- 100 MB hard drive

Recommended:

- 2 GB of RAM
- 1280 x 1024 screen resolution

Double-click the SiRFLiveInstaller\_MKTG\_Lite.msi file to install the SiRFLive program, then follow the installer directions until finished.

It is recommended that SiRFLive be installed to the default location – C:\CSR\SiRFLive.



## 5. Running the SE868-V3 Evaluation Board

1. Power will be applied to the SE868-V3 module when the USB interface is connected to a USB port on a personal computer. When the EVK On-Off switch is turned ON, the module ON\_OFF pin will be powered up and the module will begin operation.
2. Connect the provided GNSS Active Antenna.



NOTE: The evaluation kit supplies 3.3V to the antenna. For a passive antenna, jumper PL111 must be removed.


3. Place the antenna face up in a location with a clear view of open sky.
4. Use SiRFLive or TelitView to send commands to and display output from the module.



## 6. Using SiRFLive

### 6.1. Starting SiRFLive

1. Connect Power and Antenna to the EVK. See Section 5 Running the SE868-V3 Evaluation Board.
2. Turn on the EVK Power switch (up).
3. Launch the SiRFLive application. 
4. Connection Settings window: Select the Receiver. This is where you select the COM port that was previously created by the USB driver. See Section 4.1 Installing the USB Drivers. Use the **Receiver** drop-down box.




**Figure 6-1 Connection settings window**

5. If the default **Baud Rate** is 115200 and **Protocol** is OSP on your EVK, leave those boxes with their values as presented.  
If the default **Baud Rate** is 9600 and **Protocol** is NMEA on your EVK, change those boxes to match.  
If you have changed the receiver's defaults, select them using the **Baud Rate** and **Protocol** drop-down boxes.




6. Click **OK**. The remainder of these screen captures will show NMEA protocol. OSP will present somewhat different data.
7. If necessary, click Receiver, then Connect on the menu bar.



**Figure 6-2 Click Receiver, then Connect on the menu bar**


8. The SE868-V3 defaults to a power-saving mode called SiRFSmartGNSS, so you may see the GLONASS satellites disappear from the Radar View. This is normal. If you wish to command the full-time use of GLONASS as well as GPS, use the following procedure:
  - a. Click Receiver, Command, then Switch Comm Settings.



**Figure 6-3 Switch Comm Settings window**




- b. Verify that **Switch Protocol (to OSP)** and **Baud Rate of 115200** are selected as shown above.
- c. Click **Set**. The receiver and display will both switch to OSP protocol at 115,200 bps.



**Figure 6-4 The OSP protocol window**

- d. Click **Features**, **Power Mode**, then **Advanced**.



**Figure 6-5 Features, Power Mode window**





g. Verify NMEA at 9600 bps (or your desired rate), and click Set.

9. There are many additional functions available in SiRFLive. Please refer to the built-in User Manual for further details. Click **Help** in the Menu Bar, then **User Manual**.

## 6.2. SiRFLive Windows

After a successful connection with the receiver is established, the default SiRFLive windows should be arranged and become filled with data.



If not all the default windows are arranged or opened, under the Main Menu Bar, Click **Window**, **Restore Layout**, and **Default**.

### 6.2.1. Signal View



(Tool Bar icon)




Figure 6-8 Satellite signal levels



## 6.2.2. Radar View



(Tool Bar icon)



Red	$C/N_0 = 0$
Blue	$C/N_0 \neq 0$ and <u>not</u> used in the navigation
Green	$C/N_0 \neq 0$ and used in the navigation solution
Skyblue	SBAS
Circle	GPS
Square	GLONASS
Orange	ABP is being used to acquire satellites
Purple	CGEE is being used
Pink	SGEE is being used

**Figure 6-9 Satellites by azimuth and elevation**



### 6.2.3. Debug View



(Tool Bar icon)

Displays the messages incoming from the receiver




Figure 6-10 Receiver Messages (OSP )



### 6.2.4. Location View




(Tool Bar icon)



Map position button requires Internet access.

Map Position    Configuration    Clear Data    Set Reference Location



**Position Information**

Receiver Time(UTC): 18:33:21	TOw: 326016.04	Ext. Week: 1635
Latitude: 33.670878	Longitude:-117.653770	Altitude: 220.29 m
HDOP: 0.80	Speed: 0.02 m/s	Heading: 306.87°
Mode: > 4-SVs KF + Dgps		
Number of SVs used in Fix: 10	[ 11 14 16 20 23 24 25 30 31 32 ]	

Lat:33.670852, Lng:-117.653742

R = 5.00m

Auto Center

Figure 6-11 Details of the position fix



### 6.3. Logging Data



(Main Tool Bar icon)

SiRFLive can record the current message stream (OSP or NMEA) into a log file.

From the Menu Bar, click **File, Log File, Start** or click the **Log File** icon on the Tool Bar.





Figure 6-12 Log File command



Enter the desired log file path and filename in the **Log File Path** box, as shown below, then click **Start** to begin logging.



**Figure 6-13 Enter the filename to specify the log file**



## 6.4. Receiver Commands

Many of the receiver commands can be accessed through the Menu Bar under **Receiver, Command**. There are also equivalent shortcuts on the Tool Bar for frequently used commands




Figure 6-14 Receiver commands



Some receiver commands are available in One Socket Protocol (OSP) only.





## 6.4.2. Switching Protocols

On the Menu Bar, select **Receiver, Command, Switch COMM Settings**.

Click **Set** to apply settings.

OSP has many commands that are not available in NMEA. Therefore, switching to OSP is recommended for testing purposes.




Figure 6-16 Switching to OSP protocol with its default 115200 baud rate



### 6.4.3. Setting the Receiver Type

SiRFLive will normally auto-detect the connected chipset, but if not, click **Receiver**, **Receiver Family**, then the desired family.





Figure 6-17 Click Receiver, Receiver Family, then the desired family

### 6.4.4. Enabling 5Hz Update

First, set the baud rate high enough so that characters are not dropped. The default rates (9600 for NMEA and 115.200 for OSP) may be too low depending on the configured message set.

Through the SiRFLive Menu Bar, click **Receiver**, **Navigation**, **Set 5Hz Nav** and select **Enable 5Hz Nav**.





**Figure 6-18 Enable 5Hz Nav command**

The **Enable 5Hz Nav** command in SiRFLive sends the following OSP:  
**A0 A2 00 0E 88 00 00 04 04 00 00 00 00 00 00 0F 02 00 A1 B0 B3**

The **Disable 5Hz Nav** command in SiRFLive sends the following OSP:  
**A0 A2 00 0E 88 00 00 04 00 00 00 00 00 00 00 0F 02 00 9D B0 B3**



### 6.4.5. OSP MID 136 - Mode Control Command

Name	Bytes	Binary (Hex)		Unit	Description
		Scale	Example		
Message ID	1 U		88		Decimal 136
Reserved	2 U		0000		Reserved
Degraded Mode	1 U		01		Controls use of 2-SV and 1-SV solutions
Position Calc Mode	1 U		01		xxxx xxx0 = ABP, OFF xxxx xxx1 = ABP, ON xxxx xx0x = Reverse EE OFF xxxx xx1x = Reverse EE ON xxxx x0xx = 5Hz nav update OFF xxxx x1xx = 5Hz nav update ON xxxx 0xxx = SBAS Ranging use OFF xxxx 1xxx = SBAS Ranging use ON
Reserved	1 U		00		Reserved
Altitude	2 S		0000	meters	User specified altitude, range - 1,000 to 10,000
Alt Hold Mode	1 U		00		Controls use of 3-SV solution
Alt Hold Source	1 U		00		0 = Use last computed altitude 1 = User user-input altitude
Reserved	1 U		00		Reserved
Degraded Time Out	1 U		05	sec	0 = disable degraded mode, 1 to 120 seconds degraded mode time limit
DR Time Out	1 U		02	sec	0 = disable dead reckoning, 1 to 120 seconds dead reckoning mode time limit
Measurement and Track Smoothing	1 U		00000011		xxxxxxx0 = disable track smoothing xxxxxxx1 = enable track smoothing xxxxxxx0x = use raw measurements xxxxxxx1x = use smooth measurements

Table 6-1 MID 136 - Mode Control command



## 7. Updating Firmware with SiRFLive

### 7.1. Flashing Requirements

Personal Computer with a USB/COM port running SiRFLive  
Firmware file

### 7.2. Flashing Instructions

Click on **Receiver**, **Update Firmware** from the Menu Bar.





Figure 7-1 Firmware file selection




Enter the filename or browse to the firmware file.



**Figure 7-2 Select Firmware file**

Click **Update**.



**Figure 7-3 Successful firmware installation**

The new firmware will be installed, and the receiver will begin operation.



## 8. Software Interface

The host serial I/O port (UART, I<sup>2</sup>C, or SPI) supports full duplex communication between the receiver and the user.

The default UART configuration is: NMEA, 9600 bps, 8 data bits, no parity, and 1 stop bit.

Two protocols are available for data output and command input:

- NMEA-0183 V4.10
- SiRF One Socket Protocol (OSP)

### 8.1. NMEA Output Messages

Defaults:

- NMEA-0183
- 1 Hz fix rate. Maximum is 5 Hz.
- Message Set -

#### Standard Messages

Message ID	Description	Frequency
<b>RMC</b>	GNSS Recommended minimum navigation data	1
<b>GGA</b>	GNSS position fix data	1
<b>GSA</b>	GNSS Dilution of Precision (DOP) and active satellites	1
<b>GSV</b>	GNSS satellites in view.	1 / 5
Note: Multiple GSA and GSV messages may be output per cycle.		

**Table 8-1 Default NMEA Output Messages**



The following messages can be enabled by command:

Message ID	Description
GLL	Geographic Position – Latitude & Longitude
GNS	GNSS Fix Data
VTG	Course Over Ground & Ground Speed

**Table 8-2 Available Messages**

Talker ID	Constellation
GA	Galileo
GB	BeiDou
GL	GLONASS
GP	GPS
GN	Solutions using multiple constellations

**Table 8-3 NMEA Talker IDs**

### Proprietary Messages

The receiver can issue several proprietary NMEA output messages (\$PSRF) which report additional receiver data and status information.



## 8.2. NMEA Input Commands

The receiver uses NMEA proprietary messages for commands and command responses. This interface provides configuration and control over selected firmware features and operational properties of the module.

The format of a command is:

```
$<command-ID>[ ,<parameters>] *<cr><lf>
```

Commands are NMEA proprietary format and begin with “\$PSRF”.

Parameters, if present, are comma-delimited as specified in the NMEA

## 8.3. One Socket Protocol (OSP) Output Messages

SiRF One Socket Protocol (OSP) is supported. This is an extension of the existing SiRF Binary protocol. The following messages are output once per second:

- MID 2
- MID 3
- MID 4
- MID 7
- MID 9
- MID 41
- MID 64 SUB ID 2 (One message for each satellite being tracked).
- MID 138



## 9. Document History

Revision	Date	Changes
0	2015-07-014	First Issue
1	2015-07-29	Updated module photo Added photo of board with jumpers Updated component chart

