

APPLICABILITY TABLE

PRODUCT
SL869-ADR



Usage and Disclosure Restrictions

License Agreements

The software described in this document is the property of Telit and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

Copyrighted Materials

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Telit

High Risk Materials

Components, units, or third-party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

Trademarks

TELIT and the Stylized T Logo are registered in Trademark Office. All other product or service names are the property of their respective owners.

Copyright © Telit Communications S.p.A. 2016.



Contents

- 1. Introduction..... 9**
 - 1.1. Scope..... 9
 - 1.2. Contact Information, Support 9
 - 1.3. Text Conventions 10
 - 1.4. Related Documents..... 10
 - 1.5. Product Usage Notes 10
- 2. Dead Reckoning Overview..... 11**
 - 2.1. DR Description 12
- 3. Evaluation Kit Requirements..... 13**
- 4. Evaluation Kit Description 14**
 - 4.1. SL869-ADR EVK Contents..... 14
 - 4.2. SL869-ADR EVK Main Board Components 15
 - 4.3. SL869-ADR EVK Main Board Component Identification 16
 - 4.4. SL869-ADR EVK Main Board Schematic Diagrams..... 17
 - 4.5. SL869-ADR EVK Interface Board schematic 19
 - 4.6. SL869-ADR EVK Interface Board components 20
 - 4.7. SL869-ADR EVK Unit connections 22
- 5. SL869-ADR EVK Setup..... 24**
 - 5.1. Vehicle Connections 24
 - 5.2. EVK Mounting 25
 - 5.3. Computer Setup and Connection 25
 - 5.4. Install the TelitView application 26
- 6. Using TelitView 27**
 - 6.1. Main Interface 27
 - 6.2. Connecting to the EVK UART 27



6.3. TelitView Tabular View.....29

7. Flashing Firmware with TeseoIII X-Loader35

 7.1. Flashing Requirements35

 7.2. Flashing Instructions35

8. Calibration.....37

9. Document History.....39



Figures

Figure 2-1 DR Operation in the absence of GNSS signals.....	11
Figure 2-2 DR Operation Options.....	12
Figure 4-1 SL869-ADR EVK Contents	14
Figure 4-2 SL869-ADR EVK Main Board components.....	15
Figure 4-3 SL869-ADR EVK Main Board schematic – Page 1/2	17
Figure 4-4 SL869-ADR EVK Main Board schematic – Page 2/2	18
Figure 4-5 SL869-ADR EVK Interface Board schematic	19
Figure 4-6 Interface Board Components	20
Figure 4-7 EVK Unit connections – rear panel	22
Figure 5-1 Hardware Installation Warning Screen.....	25
Figure 6-1 TelitView Application Icon	27
Figure 6-2 TelitView Main Tool Bar	27
Figure 6-3 'Connect to Receiver" Window	28
Figure 6-4 Product Selection.....	29
Figure 6-5 TelitView Front Panel Status Tab.....	30
Figure 6-6 TelitView Scatter Plot Tab.....	31
Figure 6-7 TelitView NMEA Monitor Tab	32
Figure 6-8 User Menu Command Manager.....	33
Figure 6-9 DR Control Panel View	34
Figure 7-1 TESEOIII X-Loader	35



Tables

Table 4-1 SL869-ADR EVK Main Board component identification	16
Table 4-2 Interface Board –Connector P1	21
Table 4-3 Interface Board – Switch SW1	21
Table 4-4 Rear Panel - Interface Board connector P1	23
Table 4-5 Rear Panel - Interface Board switch SW1	23



1. Introduction

1.1. Scope

The scope of this document is to give an overview of:

- Operation of the SL869-ADR and its MEMS sensor related features
- Connections to a test vehicle

1.2. Contact Information, Support

For general contact, technical support, to report documentation errors and to order manuals, contact Telit Technical Support Center (TTSC) at:

TS-EMEA@telit.com
TS-AMERICAS@telit.com
TS-APAC@telit.com

Alternatively, use:

<http://www.telit.com/en/products/technical-support-center/contact.php>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

To register for product news and announcements or for product questions contact Telit Technical Support Center (TTSC).

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.



1.3. Text Conventions



Danger – This information MUST be followed or catastrophic equipment failure or bodily injury may occur.



Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.



Tip or Information – Provides advice and suggestions that may be useful when integrating the module.

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.

1.4. Related Documents

- SL869-ADR Product User Guide
- SL869-ADR Software User Guide

1.5. Product Usage Notes



- To prevent ESD and EOS damage, a properly grounded ESD wrist strap should be worn when the EVK case is opened
- Do not alter jumpers while power is applied
- Do not short the RF signal to ground if antenna supply voltage is connected. Damage to the EVK or module may occur.



Always follow ESD safety precautions when utilizing the evaluation kit. For additional information, contact your local sales representative.

This module shall be supplied by a limited power source complying with clause 2.5 of EN 60950-1 and mounted on a VI flammability class material or better.



2.1. DR Description

In a DR configuration, a discrete odometer or wheel pulse signal provides the unit with vehicle speed data. This signal may be obtained from various locations in the vehicle such as the transmission, speed display or a port on some car radios. The SL869-ADR can accept odometer input pulses in the range of 12V.

An option for supplying the odometer or wheel tick pulse is through the on-board diagnostics (OBDII) connector, which provides access to the vehicle’s controller area network (CAN) bus. This can be achieved with the addition of an “OBD VSS Signal Generator” - a device that generates a wheel pulse from the vehicle CAN bus data. Telit does not sell these devices.

Note: Telit currently does not support the direct connection of a CAN bus.

A forward-reverse signal, usually provided by the vehicle’s transmission or a backup light circuit, supplies directional data to the SL869-ADR module. For proper operation, the reverse signal should be stable when on and not be pulsed.

The SL869-ADR Evaluation Kit (EVK) has a selection switch to invert the signal if necessary.

The SL869-ADR module also includes a set of MEMS gyros that are capable of measuring rates of angular motion around three axes, allowing the unit to maintain vehicle attitude data – heading, pitch, and roll angles.




Figure 2-2 DR Operation Options



3. Evaluation Kit Requirements

To use the SL869-ADR Evaluation Kit (EVK), you will need the following items:

1. An SL869-ADR Evaluation Unit
(ADR programmed receiver is included in the kit)
2. FTDI USB Drivers (included on the USB flash drive)
3. Current version of TelitView

Note: There is a version of TelitView on the USB Drive supplied in the kit, however for full functionality, the latest version should be downloaded from the Telit Support Site.

4. A PC with a USB port and:
 - Windows 7 or later
 - .NET Framework 4.0
5. A test vehicle equipped with available wheel tick odometer pulse



4. Evaluation Kit Description

4.1. SL869-ADR EVK Contents




Figure 4-1 SL869-ADR EVK Contents



4.2. SL869-ADR EVK Main Board Components

The SL869-ADR Unit contains a main board with an interface board mounted on top.
The main board PL103 connects to interface board J1.



Note: PL105 and PL106 must be jumpered 1-2 to operate the on-board Teseo 3 Antenna Sense circuit.

Figure 4-2 SL869-ADR EVK Main Board components

Required External Connections

Connect the PC to UART-USB (PL102)

Connect the GNSS antenna to RF-IN (SO101)

Connect Forward/Reverse and Wheel Tick vehicle signals to the Interface Board connector




4.3. SL869-ADR EVK Main Board Component Identification

SL869 Main Board Components		
ID	Name	Description
DL101	TX LED	TX data line display
DL102	1PPS LED	1PPS output line display
SW 201	ON/OFF Switch	Applies power to the EVK.
SO 102	1PPS Output SMA	1PPS buffer output connector
PL 108	SL869 BOOT Pin	To place the module into BOOT mode, place a shunt jumper on pins 2 & 3 before powering the unit up. Not connected for normal operation.
PL104	Vcc Supply	Place a shunt jumper to apply 3.3 V to the module Vcc. Required for normal operation.
PL 107	Vbatt Supply	Place a shunt jumper to apply 3.3 V to the module Vbatt. Required if standby power is desired when Vcc is removed.
PL 102	UART-USB1	USB: DC, Ground, TX, RX. Connect to laptop.
PL 101	USB2	Reserved
PL 113	Vant Supply	Place a shunt jumper to apply 3.3 V to the SMA connector for an external active antenna.
PL 201	+3.3 V LDO Antenna supply	Pins 1 & 2: Power LDO_Enable with On/Off switch Pins 2 & 3: Power LDO_Enable with module Pin 4 output
SO 101	Antenna SMA	Antenna: RF Input + Vant

Table 4-1 SL869-ADR EVK Main Board component identification



4.6. SL869-ADR EVK Interface Board components



Note: MEMS devices are not installed on the Interface Board since they are included in the SL869-ADR module.

Figure 4-6 Interface Board Components



Interface Board - Connector P1	
Pin	Description
1	VBAT (9-12VDC)
2	GND
3	REVERSE IN (see SW1-switch 2 for polarity)
4	WHEEL/ODO IN Pulse
5	Reserved
6	Reserved

Pin 1 is closest to the (top) board edge

Table 4-2 Interface Board –Connector P1

Interface Board - SW1	
Switch	Description
1	No Connection
2	<u>Invert the Reverse signal</u> UP: +12V = Forward DOWN: +12V = Reverse
3	Reserved
4	Reserved

SW 1 is closest to the (bottom) board edge

Down position (closest to the board) is OFF

Table 4-3 Interface Board – Switch SW1



4.7. SL869-ADR EVK Unit connections




Figure 4-7 EVK Unit connections – rear panel



Rear Panel - Connector P1	
Pin	Description
	+12V (9 to 12 VDC)
	Ground
	Reverse Signal (see SW1-switch 2 for polarity)
	Wheel/Odo Signal (pulse)
	Reserved
	Reserved
The +12V pin (red) is closest to the right edge	

Table 4-4 Rear Panel - Interface Board connector P1

Rear Panel - SW1	
Switch	Description
1	No Connection
2	<u>Invert the Reverse signal</u> Up: +12V = Forward Down: +12V = Reverse
3	Reserved
4	Reserved
SW 1 is closest to the left edge	
Down position is OFF	

Table 4-5 Rear Panel - Interface Board switch SW1




5. SL869-ADR EVK Setup

5.1. Vehicle Connections

- The SL869-ADR EVK main board is powered by the USB cable connected to a PC.
- Vehicle signals can be connected to the SL869-ADR Interface Board connector P1 (on the EVK Unit rear panel) using the DR harness cable provided as follows:

1. An external 12 VDC supply is required.
 - RED (Pin 1): +12V
 - BLACK (Pin 2): Ground
2. A reverse signal from the vehicle is required.
 - WHITE (Pin 3): Reverse signal (input)
3. The polarity of the reverse signal is set by SW1-switch 2 on the rear panel of the EVK to suit the installation.
 - If +12V signals Forward, set SW1-switch 2 UP
 - If +12V signals Reverse, set SW1-switch 2 DOWN
 - If not connected (e.g. for test purposes), set SW1-switch 2 UP to indicate Forward gear.

SW 2 Setup



4. A wheel tick signal is required.
 - GREEN (Pin 4) Wheel Tick / ODO



5.2. EVK Mounting

The EVK must be positioned near the center of the vehicle and mounted securely.
The EVK must be mounted flat and with the front panel facing the front of the vehicle.

5.3. Computer Setup and Connection

Before operation, ensure that the EVK power switch is in the OFF (down) position and the USB drivers are installed by performing the following steps:

1. Insert the USB flash drive and connect the EVK to the PC via the USB-1 connector on the rear of the EVK. Then, turn the Power switch vertically UP to turn On the EVK.
2. As soon as the evaluation board is connected to the PC, it will be detected and the USB driver installed.
3. Note: If a software Installation warning appears, select “Continue Anyway” option.



Figure 5-1 Hardware Installation Warning Screen


4. After the EVK is connected, check the “Device Manager” window for the evaluation board COM port number. This information is needed for use with the GPS tools.
5. Connect the provided Active Antenna to the SMA connector.

NOTE:



On some occasions, Windows will install a Microsoft Serial BallPoint mouse after connecting the USB. Uninstall the Microsoft Serial BallPoint mouse if Windows mistakenly installs it.





Select “SL869-ADR”, not SL869-3DR as shown above.

Figure 6-4 Product Selection

6.3. TelitView Tabular View

TelitView implements a tabular view. Switching between tabs displays different information parsed from the receiver.

- **Front Panel Status**
The Front Panel Status Tab displays satellite information as well as position information.






Figure 6-5 TelitView Front Panel Status Tab



- **Scatter Plot**
The Scatter Plot displays position points that are updated every second. The position points are compared to each other in an axis in meters.




Figure 6-6 TelitView Scatter Plot Tab



- **NMEA Monitor**
The NMEA Monitor displays the NMEA output of the receiver. The user can also type in commands in the Transmit toolbar. In order to pause the “Receive” screen, right-click on the window and select “Pause receive”




Figure 6-7 TelitView NMEA Monitor Tab



- **User Menu Command Manager**
The user has the option to enter basic commands by clicking on the “Commands Tab”. There are 18 available basic commands.




Figure 6-8 User Menu Command Manager



5. Click on the Load button then locate and select the provided software by Telit.
6. Verify selections as follows:
 - “Target device” is SQI flash
 - “Loading settings” is UART mode
 - “Options” is “Erase NVM”
 - “STA8090FG Only” is selected
7. After selecting the correct configuration and the selected COM port is properly identified (Look under Device Manager in Windows OS for COM port if cannot be identified/found), click on “Send” to program the device.
When done, a pop up window will confirm, “Device successfully programmed”.
8. Remove the shunt jumper from Step 1.
9. Cycle power to EVK. Verify NMEA data is streaming out with TelitView under the NMEA Monitor window.



8. Calibration

Once the system has been installed with desired firmware and connected to vehicle wheel ticks, proper calibration is required for optimum performance.

Steps:

1. First, choose a location where there is open sky over the entire course for a good GNSS signal. Calibration will require the vehicle to be moving.
2. Place the EVK on a flat and secure surface with the power switch facing toward the front of vehicle and as close as possible to the center of vehicle. This will allow the gyro to stabilize and the DR FW to store starting point parameters. Once oriented in this position, it should remain in same direction and location to keep results consistent.



Ensure a rigid mount.

3. Connect USB from the laptop PC to the EVK port USB1, located at opposite side from the SMA antenna connection.
4. Run TelitView on the laptop to verify NMEA output activity from the EVK when powered on. TelitView will also allow you to see and record data from the EVK output.
5. Turn on car and the power up the EVK.
6. Synchronize the EVK to Telit view.
Note: Make sure to select correct COM port and set baud rate 115200.
7. Wait approximately 2 minutes in a stopped position with the EVK and vehicle on. This allows the unit to initialize the yaw rate offset with reliable values. Verify a valid GNSS position fix.
8. After 2 minutes, drive in a straight line direction for at least five minutes at a constant speed. The speed should be greater than 35 km/h (approx. 22mph).
9. Following the straight drive, make several left and right turns of at least 90 degrees allowing the system to calculate the gyro yaw rate gain.
Note: Calibration will be improved with more turns completed. A minimum of 10 turns is recommended.
10. Calibration should be performed in an open sky environment. Avoid urban canyons, tunnels, parking garages, dense foliage, etc.



To complete calibration, the vehicle should stop and remain stationary for at least 10 seconds. For a full calibration to be successful, the above procedure must be followed.

11. Verify through the TelitView DR Control Panel that the DR Calibration Status fields are all checked and highlighted in green as shown in **Figure 6-9 DR Control Panel View**.
Another way to verify that calibration is completed is by checking NMEA message **\$PSTMDRCAL,A,B,C,D,xx**
If the highlighted fields (A, B, C, D) have values of '1', a coarse calibration was achieved.
12. To clear calibration (for testing purposes), click the "Clear Cal" button on the TelitView DR Control Panel screen. Follow the instructions and issue a reset to complete the process.



9. Document History

Revision	Date	Changes
0	2016-08-19	First Issue

