

SC872-A Evaluation Kit User Guide

1VV0301188 Rev.0 – 2015-02-06



SC872-A Evaluation Kit User Guide
 1VV0301188 Rev.0 – 2015-02-06

7.2. Flashing Instructions 23

8. NMEA-0183 Messages and Commands..... 28

8.1. COM Port (serial) 28

8.2. NMEA Output Messages..... 28

8.3. NMEA Input Commands 30

8.4. Commands Description 31

9. Document History 32



1. Introduction

1.1. Scope

This document provides information on using the SC872-A Evaluation Kit.

1.2. Contact Information & Support

For general contact, technical support, to report documentation errors and to order manuals, contact Telit Technical Support Center (TTSC) at:

TS-EMEA@telit.com
TS-AMERICAS@telit.com
TS-APAC@telit.com

Alternatively, use:

<http://www.telit.com/en/products/technical-support-center/contact.php>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

To register for product news and announcements or for product questions contact Telit Technical Support Center (TTSC).

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.

1.3. Text Conventions

- All dates are in ISO 8601 format, i.e. YYYY-MM-DD.



Danger – This information MUST be followed or catastrophic equipment failure or bodily injury may occur.



Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.



Caution – Risk of explosion if battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions



Tip or Information – Provides advice and suggestions that may be useful when integrating the module.



2. Product Overview

The SC872-A Evaluation Kit packages the SC872-A Module in a plastic case containing the necessary interface components and a cable with a USB connector.

The SC872-A module contains a GNSS receiver with integrated antenna based on the MediaTek MT3333 chipset. It also includes a high performance LNA, TCXO, SAW filter, RTC, Backup battery, and LDO.

The receiver can simultaneously search and track satellite signals from the entire spectrum of GNSS constellations available: GPS, Glonass, Galileo, BeiDou, QZSS and SBAS. However, the antenna is designed for GPS and GLONASS bands, therefore a wider bandwidth antenna should be used to verify BeiDou performance.

Communication is performed over a UART serial port using the NMEA-0183 protocol.

The SC872-A features high sensitivity, low power consumption and fast Time To First Fix (TTFF). It also supports jamming immunity.

The EVK supplies power from the USB interface to the module.



3. Evaluation Kit Requirements

To use the SC872-A Evaluation Kit (EVK), you will need the following items:

1. An Evaluation Kit with a programmed/flushed module
 - Current Firmware (FW) build for the installed module (if necessary)
2. FTDI USB Drivers (included on the USB flash drive)
3. Current version of TelitView (included on the USB flash drive)
4. A PC with a USB port and:
 - Windows 7 or later
 - .NET Framework 4.0



4. Evaluation Kit Description

4.1. Evaluation Kit Contents



Figure 4-1 SC872-A Evaluation Kit Contents



4.3. SC872-A Product



Figure 4-4 SC872-A Product



5. Evaluation Kit Setup

5.1. Installing the USB Drivers

1. Before connecting the evaluation kit, ensure that the FTDI USB drivers are installed.
If needed, install the drivers from the USB flash drive by double-clicking the USB driver executable and following the onscreen directions.
2. Verify that the proper jumpers have been installed.
3. Connect the provided Active Antenna to the SMA connector.
4. Connect the evaluation kit to the PC. It will automatically be detected and the USB driver will be installed. If the system does not automatically find the driver, the user may provide the path to the USB drive.
5. Select "Continue Anyway" to proceed



Figure 5-1 USB Installation message

6. After the device driver has been installed, the user should check the “Device Manager” in Windows for the evaluation board COM port number to be present. This port number is required by TelitView or other software to communicate with the EVK.
7. Turn power on to EVK.





NOTE:

After installation of the USB FTDI driver, Windows may install a “Microsoft Serial BallPoint mouse” if the EVK is powered on when connecting the USB cable.

If this happens, it will show up on the “Device Manager” under “Mice and other pointing devices”. If this is displayed, power the EVK off, disconnect it from the USB port, and uninstall the “Microsoft Serial Ball Point mouse”. Then, reconnect the EVK while powered off, and verify that it is now displayed as a USB serial com port under “Ports (COM & LPT)”.



6.2. Connecting to the EVK

6.2.1. Selecting the baud rate

1. Connect the EVK to a USB port while it is powered OFF.
2. On the Main Menu, click Setup.




Figure 6-2 TelitView Main Menu - Setup

3. Click “Comm Port”, select the proper serial port, select the baud rate, then click OK.




Figure 6-3 TelitView Com port selection



SC872-A Evaluation Kit User Guide
1VV0301188 Rev.0 – 2015-02-06

- Power up the EVK and if connected properly, the NMEA Monitor window should display output messages every second as shown below (outlined in red).




Figure 6-4 TelitView Main Session

6.3. TelitView Functions



NOTE: If “Session configuration” prompts to save Setup, click YES.
For detailed illustrated instructions on TelitView operation, click on the “Help” option in the main Tool Bar, and select User’s Manual.

6.3.1. Setup Menu

The setup menu allows the user to specify setup parameters as follows:

- Comm Port – Allows the user to set up the appropriate Com port and baud rate.
- Replay – Allows the user to replay a previously recorded data file.
- Disconnect – Allows the user to disconnect the Com Port
- Start Log – Allows the user to start recording a log file
- Stop Log – Allows the user to stop recording a log file
- Products – Allows the user to select which Telit module is under test.
Note: Be sure to select SC872-A when connecting to the SC872-A module.
- Sessions – Allows the user to configure or save a session (specifying Comm port, Baud Rate, etc.)
- Exit – Allows the user to terminate the program.



6.3.2. View Menu

The main View Screens should be active as shown above in Figure 6-4 TelitView Main Session. They are described as follows:

- Navigation States – Date, Time and Navigation data
- NMEA Monitor –Receiver NMEA input commands and output messages.
- Signal Quality –Tracked satellite’s signal strengths
- Azimuth Elevation –Visible satellites’ position (azimuth and elevation). The center of the plot represents the antenna position.
- Scatter Plot – Plot of the horizontal position and tracks. Also displays the position update and horizontal error.

Additional View Screens are accessible by clicking the “View” Tab:

- Data Overview – The navigation data in a tabular form.
- Data Charts – Time-sequenced navigation data. Parameters listed are Latitude, Longitude, Altitude, Speed, HDOP, SVs in View, and SVs in Use.
- DR States - DR Data
- Custom Messages Window –Allows the user to select and display custom messages.

6.3.3. Tools Menu

- Allows the user to replay previously recorded data files (play, pause, and stop).
- Allows the user to manage the user-defined commands.

6.3.4. Commands Menu

The Commands menu provides the user with options to enter a choice of either Basic or user Defined Commands.

- Basic Commands: These are built-in Commands provided by TelitView, e.g. to select the satellite constellation of choice (GPS only, GPS + GLO, or GPS + BDS).
- User Commands: These Commands are created and maintained by the user (under the Tools menu). They can be customized for customer specific applications.

6.3.5. Test Menu

- Allows the user to enter a Reference Position for comparison to actual test results
- LoopIt test is an automatic repeated test (for TTFF).



6.3.6. Windows Menu

The Windows option is for screen management. Any changes by the user in the placement of the set of windows will be arranged as described in the drop-down menu. For the default configuration, restart TelitView.

6.3.7. Help Menu

- Displays the version of TelitView in use
- Displays the built-in User's Manual (which includes a list of the Tool Bar Icons and their functionalities).



7. Updating Firmware with Telit Power Flash

7.1. Flashing Requirements

The Folder is on the USB Flash Drive included with the EVK

- TPF_SC872-A.exe software from TELIT
- Set of three files (in folders DA, SCAT, and ROM)
Some of these folders may become visible when TPF_SC872-A is started.
- brom.dll

7.2. Flashing Instructions

1. Copy the “TPFlash for SC872-A” folder onto the host PC from the USB flash drive.
2. Connect the Evaluation Kit to USB port
3. Launch Telit Power Flash by double clicking the TPF_SC872-A.exe icon located in the above mentioned folder. A COM port will be selected. If the port is not the same as the one displayed in the Device Manager (for the correct USB Serial Port), please select the correct COM port.




Figure 7-1 Telit Power Flash Com Port



4. Click on the “Flash” button and the FW upgrade will start after about 3 seconds.




Figure 7-2 Processing Download Agent

5. When the first Open dialog window pops up, look at the “Files of type” box at the bottom of the window to determine what file type should be selected.
The first one will be the “Download Agent File”.



10. If you see a “Download Fail” message, it is most likely that you do not have the correct COM port specified. Check the Device Manager – Ports (COM & LPT) for the correct USB Serial Port.
11. The Download Agent will now transfer (about 20 seconds).
12. The ROM file will now transfer (about 1.5 minutes).
13. The final message will be displayed. Click the red “X” to close the window.




Figure 7-7 TPF_SC872-A Download completed

14. Connect an antenna to the EVK and verify its operation.



8. NMEA-0183 Messages and Commands

8.1. COM Port (serial)

The user interface with the EVK is serial data connected through a serial-to-USB converter. The default port settings are:

- 9600 Baud
- 8 Data Bit
- No Parity Bit
- 1 Stop Bit

Data can be sent and received through the use of a PC terminal emulator program or an application program like TelitView.

8.2. NMEA Output Messages

NMEA-0183 v4.10 is the default protocol.

In the current Firmware release, some sentences may exceed the NMEA length limitation of 80 characters.



By default, GPS, SBAS and QZSS constellations are enabled.
For the SC872-A GLONASS is also enabled by default.

The default fix rate is 1 Hz.



These messages are output once per second by default.
Multiple GSA and GSV messages may be output on each cycle.

- **Standard Messages**

Message ID	Description
RMC	GNSS Recommended minimum navigation data
GGA	GNSS position fix data
VTG	Course Over Ground & Ground Speed
GSA	GNSS Dilution of Precision (DOP) and active satellites
GSV	GNSS satellites in view.
\$PMTK010	System messages (e.g. to report startup, etc.)

Table 8-1 Default NMEA output messages

The following messages can be enabled by command:

Message ID	Description
GLL	Geographic Position – Latitude & Longitude
ZDA	Time & Date

Table 8-2 Available Messages

Talker ID	Constellation
BD	BeiDou
GA	Galileo
GL	GLONASS
GP	GPS

Table 8-3 NMEA Talker IDs



- **Proprietary Messages**

The SC872-A supports several proprietary NMEA periodic output messages which report additional receiver data and status information.

8.3. NMEA Input Commands

The SC872-A uses NMEA proprietary messages for commands and command responses. This interface provides configuration and control over selected firmware features and operational properties of the module.

The format of a command is:

```
$<command-ID> [ , <parameters> ] * <cr> <lf>
```

Commands are NMEA proprietary format and begin with “\$PMTK”. Parameters, if present, are comma-delimited as specified in the NMEA protocol.

Unless otherwise noted in the Software User Guide, commands are echoed back to the user after the command is executed.



9. Document History

Revision	Date	Changes
0	2015-02-06	First issue

Figure 9-1 Document History

